



MPPPS
MOUNT PLEASANT POWER SYSTEM

Typical 200 Amp Underground Service (Stub Pole with Unistrut)

1. Obtain the meter location from MPPS prior to installation.
2. Purchase and install an approved meter base from MPPS.
3. Excavate a trench from the meter to the electric pole or pad. Customer is responsible for having underground facilities located prior to digging. (TN One Call dial 811)
4. Install a 3" PVC conduit with pull rope from meter to pole or pad. Leave conduit and a 3" weatherhead for power pole riser at the base of the pole.
5. For mobile homes meter must be no further than 30' from the mobile home.
6. Obtain a trench inspection from MPPS and install marking tape before covering trench.
7. Apply for MPPS Electric Service and pass State Electric Inspection. Leave Main disconnect in the "open" position.

